

**Need Press «RESET» then the Sensor work as Pre-set else the fixture just as regular fixture**

#### ON/OFF Permanent ON/OFF Function

Press the ON/OFF Button, the light goes to permanent On or permanent OFF  
Press «RESET» button to quit from this mode.

#### Reset Reset function

Press «RESET» Button, all settings go back to factory default settings as follow :

<b>100%</b>	<b>5min</b>	<b>10min</b>	<b>Disable</b>	<b>10%</b>
detection range	hold time	stand-by period	daylight sensor	stand-by dimming

#### Detection range

Select as appropriate to adjust/reduce sensor sensitivity ; 100% or 50%

#### Hold Time

Hold time refers to the time period that the light remain 100% on if no more movement detected

#### Daylight sensor

Select daylight sensor threshold level at 30lux. Ambient light must be below this lux to turn light on.

Press LUX disable button to always turn on when motion is detected

#### Stand-by period (tri-level control)

Press the buttons of "stand-by period" to set stand-by period at 10s / 3min / 10min / +∞

Note: "+∞" means bi-level control, light never switches off .

#### Stand-by dimming level

Press the buttons of "stand-by dimming level" to set the stand-by dimming level at 0% / 10% / 30% / 50%.

**Note: "0%" means on/off control**

